INSTALLATION INSTRUCTION

LED Beauty Spot Canopy

DR-LED302

WAC LIGHTING Responsible Lighting®

SAFETY INSTRUCTION

IMPORTANT: NEVER attempt any work without shutting off the electricity.

- Read all instructions before installing.
- Installed by a qualified electrician
- Fixture is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.
- To reduce the risk of fire, electrical shock and injuries to persons, turn off power at main switch before installing or modifying the system.
- Retain instructions for future maintenance reference.

OVERVIEW

Intended ceiling, cabinets and display. Fixtures use a LED, 100mA maximum (used with 24 volt power supply). Fixture is held in place by spring tension against the cut out hole.


INSTALLING FIXTURE:

- 1. Run a wire from a remote transformer to the fixture site (use 24 volt listed transformer, not supplied).
- 2. Cut a 2 3/8" diameter opening on the mounting surface.
- 3. Bring the wire through the hole.
- 4. Loosen the two screws on either side of can to remove and access the socket wires.
- 5. Remove the knock out in the can and install the appropriate wire clamp.
- 6. Connect "output" wires from the transformer to the socket wires with wire nuts provided.
- 7. Tuck wires under the can and re install with the two screws removed earlier.
- 8. Compress the leaf springs on either side of the housing and insert into the cut out hole.


INSTALLING SHADE:


- Shades will fit over the lamp and are held in space by a spring band at the base of the socket, simply push on or pull off.
- 2. Shades sold separately. Use shades from the "DR" series.

Retain instructions for future reference.



Compress the leaf spring.





Shade shown is the DR-G361-CL