


# ASSEMBLY & INSTALLATION INSTRUCTIONS

A976

Linear Passage Pendant 131080



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING  
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM

## Component Parts

- A Fixture**
- B Canopy**
- C #10 Screws (8)**
- D Anchors (8)**
- E Canopy Plate**
- F Swivel (2)**
- G Stud (4)**
- H 3" Fixture Pipe (2)**
- I 6" Fixture Pipe (2)**
- J 12" Fixture Pipe (6)**
- K Stem Couplings (8)**
- L Safety Cable(2)**
- M Nut (2)**
- N Washer (2)**
- O Socket (10)**
- P Bulb (not included)**
- Q Glass (8)**
- R O-Ring (16)**
- S Socket Cup (8)**
- T Barrel Knob (4)**



# ASSEMBLY & INSTALLATION INSTRUCTIONS

A976

Linear Passage Pendant 131080

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Please Note: After installation extra hardware and accessories are possible due to our kits are used on multiple products and options.

## To Install Canopy (Figure 1) on following page

**CAUTION: BE SURE POWER IS OFF AT THE MAIN BREAKER BOX PRIOR TO INSTALLATION.**

1. Carefully unpack canopy the carton.
2. Center the canopy (B) over the electrical box. Be sure to line up oval slots in bracket with mounting holes in electrical box. With a pencil, mark the location of all mounting holes in the canopy (B) on the ceiling

**CAUTION:** Due to weight of fixture, be sure at least two #10 screws (C) attach canopy (B) to a structural member in the ceiling. No anchors (D) will be needed in those locations. We've supplied wood screws with your fixture, however, different materials and/or construction methods may require different fasteners. If in doubt, contact a qualified electrician.

**Caution:** Do not rely on anchors alone to suspend fixture. Fixture must be attached to a structural member in the ceiling.

3. Drill 1/4" holes in the locations marked on the ceiling. Place the tapered end of the anchors (D) into the holes and gently tap them flush to the ceiling using a light weight hammer.
4. Thread the wires in the electrical box through the hole in the canopy (B) while moving the canopy into position. Using two machine screws (not provided) fasten canopy (B) to the electric box.

**Note:** A new electric box comes with screws. When replacing a fixture, retain the existing screws for use with the new fixture.

5. Using the #10 screws (C), secure canopy (A) securely to ceiling. Be careful not to over-tighten or strip anchors (D).
6. Using suitable wire connectors (not provided) connect fixture wires to supply wires (white to white and black to black). Connect all ground wires (bare copper or green to bare copper or green) together.

**CAUTION: MAKE SURE WIRE CONNECTORS ARE TWISTED ON SECURELY, AND NO BARE WIRE IS EXPOSED.**

7. Follow instructions on following page to install fixture.



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING  
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM


54339

3 OF 6

# ASSEMBLY & INSTALLATION INSTRUCTIONS

A976

Linear Passage Pendant 131080



(Figure 1)

## To Install Fixture (Figure 2) on following page

1. Carefully unpack fixture from the carton.
2. Locate fixture pipes (H,I,J), fixture (A), stem coupling (K). Stem couplings (K) can be found in the kit bag.
3. Provided are multiple fixture pipes in three different lengths. Choose the combination that will achieve the overall height desired. Refer to the table below to determine the pipes required to reach the desired overall height. Once you have determined the components necessary, feed the wires that exit fixture (A) through the individual components. Wires will slip easier through loose components than through pipes and couplings that are pre-assembled. Once wires are run, apply thread locking compound to all the connection points and assemble the pipes and nipples.

		Overall Height of Fixture									
		25.0	28.0	31.0	34.0	37.0	40.0	43.0	46.0	49.0	52.0
# of Pipes Required	3" Pipe (H)		1		1		1		1		1
	6" Pipe (I)	1	1			1	1			1	1
	12" Pipe (J)	1	1	2	2	2	2	3	3	3	3

**NOTE:** APPLICATION OF THE THREAD LOCKING COMPOUND IS NECESSARY TO PREVENT THE PIPE FROM LOOSENING DURING REGULAR MAINTENANCE AND CLEANING OF THE FIXTURE. BE CERTAIN TO APPLY THE COMPOUND.

4. Slip wires from the fixture (A) through assembled swivel (F) and thread swivel into fixture pipe.
5. Repeat repeat steps 3 & 4 for second set of pipes.
6. Ensure that slots on swivels (F) are aligned as shown in figure 2.
7. Follow instructions on following page to continue install.

# ASSEMBLY & INSTALLATION INSTRUCTIONS

A976

## Linear Passage Pendant 131080


- Carefully place canopy plate (E) over swivels (F) and secure with washer (N), safety cable (L) and nut (M) as shown. Washer (N), safety cable (L) and nut (M) can be found in the kit bag.
- Lift fixture assembly (A) up to canopy (B) and place safety cables (L) over loops.
- Using suitable wire connectors (not provided) connect fixture wires to supply (white/ribbed to white and black/smooth to black). Connect all ground wires (bare copper or green to bare copper or green).

**CAUTION:** MAKE SURE WIRE CONNECTORS ARE TWISTED ON SECURELY, AND NO BARE WIRE IS EXPOSED.

- Align the holes in canopy plate (E) with studs (G) and secure with knurled balls (T).

**CAUTION:** BE SURE NO WIRES ARE PINCHED BETWEEN CANOPY (B) AND THE CEILING.

- Refer to instructions on next page to Install Glass.



(Figure 2)

Linear Passage Pendant 131080

## To Install Glass *(Figure 3)*


1. Unpack glass (Q) and locate o-ring (R), found in kit bag.
2. Stretch o-ring (R) over one end of glass (Q). Leave just slightly up from bottom of glass.
3. Install T type bulb (P) (not included) into socket (O) .
4. Place glass (Q) over T type bulb (P).

**NOTE: All glass tolerance is designed for the recommended T type bulb. If a piece does not fit, verify correct bulb type and size is being used.**

5. Slide glass (Q) and o-ring (R) into socket cup (S) until it hits bottom of cup.

**NOTE: O-rings are optional, and can either use one, two, or none depending on what's needed to help with gaps. Be sure O-rings slide into cup. It may be necessary to rotate glass or push on O-rings to allow them to slide into cup evenly.**

6. Repeat steps for remaining sockets (O) and glass (S).
7. Restore electricity at main breaker.



(Figure 3)

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

*\* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.*