



ASSEMBLY INSTRUCTIONS FOR YOUR CLARE FLOOR EASEL

IMPORTANT SAFETY INSTRUCTIONS:

*This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.

*Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.

*Switch power off and remove plug from the wall outlet before replacing the bulb.

*This lamp is UL rated for dry locations.


ASSEMBLY INSTRUCTIONS:

Note: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and place them on a level surface.
2. Insert one (1) 60W MAX. Medium base bulb into socket located inside shade (A).
3. Adjust position of shade (A), by rotating shade at ball swivel (B) or loosen turn knobs (C) and (D) (one at a time) to adjust the location of the shade at either joint. Tighten turn knobs (C) and (D) to secure the position of the arms.
4. To adjust height of clamp (F), loosen turn knob (G). Carefully slide clamp (F) up and down column (H) until desired position is reached. Tighten turn knob (G) to secure position of clamp (F) on column (H). Repeat steps for the second clamp.
5. To adjust the depth of clamp (F), loosen turn knob (E). Carefully slide clamp (F) into the desired position. Tighten turn knob (E) to secure the position of clamp (F). Repeat steps for the second clamp.
6. Remove protective plastic from polarized plug (J). Insert polarized plug (J) into wall outlet.
7. Adjust the lumens of the bulb by adjusting the switch position on dimmer (I). Please note this is a full-range dimming switch and a dimmable bulb is required for the best results.

Note: 20 LBS. MAX weight for artwork. Max frame depth 2.25".

*** To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. ***



BB16BB