

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.:DWC50	NAME: GARLAND SCONCE
MATERIAL TYPE: METAL	FINISH: ANTIQUE BRASS
SOCKET TYPE:: LED	SOCKET QTY: 1
BULB WATTAGE: 7W	
VOLTAGE: 100V-120V	ITEM NET WEIGHT: 4LBS





PLEASE IGNORE THIS DEVICE ON THE BACK PLATE.

PARTS INCLUDED:

Mounting Plate(A)	Qty: 1PC
Canopy Screw(C)	Qty:2PCS
Back Plate(D)	Qty: 1PC
Mounting Screw(J)	Qty:2PCS
Plastic Wire Connector(K)	Qty:3PCS

HARDWARE INCLUDED:

Mounting Screws	Qty: 2PCS
Canopy Screws	Qty: 2PCS
Green Ground Screw	Qty: 1PC
Plastic Wire Connector	Qty: 3PCS

TOOLS NEEDED (Not Included):

1 Screwdriver


These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.


We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/circuit breaker.
- 2. Carefully unpack all fixture parts and hardware and lay, them on a soft surface for assembly.
- 3. Gently pull wiring down from junction box and allow to hang.
- 4. Remove the mounting plate(A) from the back plate(D) by loosening the canopy screw (C)using a Phillips screwdriver.
- 5. Place the mounting plate(A) over the center of the junction box.
- 6. Align the holes in the mounting plate (A) with the holes in the junction box and secure it with two mounting screws (J). Secure the screws using a Phillips head screwdriver.
- 7. Connect ground wire from wall to ground wire from lamp using wire caps (K).
- Attach house wire to lamp wires as shown. Fasten the pairs together with a wire caps
 DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 9. PLEASE PAY SPECIAL ATTENTION TO THE FACT THAT YOU DO NOT NEED TO CONNECT THE WIRE TO THE DEVICE (M). IT IS USED FOR WIRE CONNECTIONS IN THE EUROPEAN MARKET.
- 10. Finally, please note that this product is suitable for 0-10V dimmer switches. Connect the purple wire (+) and the gray wire (-) to the dimmer switch as shown in Figure 1. Ensure that no strands are exposed. BE SURE NO STRANDS ARE EXPOSED.
- 11. Gently tuck the wire connections(K) neatly into the junction box.
- 12. Attach the back plate (D) to the mounting plate (A) using 2 set screws (C), and tighten them with a screwdriver.
- 13. Restore power to junction box and test fixture.





CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.