


ASSEMBLY & INSTALLATION INSTRUCTIONS

A1052

SPIRE PENDANT 181604



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM

Component Parts

- A Fixture**
- B Steel Spinning**
- C Crossbar**
- D Jam Nut**
- E Threaded Nipple**
- F Ground Screw**
- G Canopy Ring**
- H Canopy**
- I Swivel**
- J 3" Fixture Pipe**
- K 6" Fixture Pipe**
- L 12" Fixture Pipe (3)**
- M Stem Nipple (6)**
- N Metal Washer (2)**
- O Rubber Washer (2)**
- P Glass**
- Q Half ball**
- R Bulb (not included)**




SPIRE PENDANT 181604

To Assemble Fixture *(Figure 1)*

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*


Please Note: After installation extra hardware and accessories are possible due to our kits are used on multiple products and options.

1. Carefully unpack fixture (A) from the carton.
2. Locate fixture (A), Steel Spinning (B), Metal Washers (N), Rubber Washers (O), Glass (P) and Half Ball (Q). Slide Fixture (A) through the top hole in the Steel Spinning (B).
3. Screw stem nipple (M) into the top of Fixture (A).
4. Screw half ball on stem nipple (M) with the larger side facing down (See figure 2).
5. Slide glass (P) over stem nipple (M) until it rests on the half ball (R).
6. Slide rubber washer (O) and then metal washer (N) over stem nipple (M) until they rest on glass (P).
7. Gently screw 3" pipe (J) onto stem nipple (M) until tight against metal washer (N).



(Bottom)

(Figure 2)



(Figure 1)



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM

ASSEMBLY & INSTALLATION INSTRUCTIONS

A1052

SPIRE PENDANT 181604

To Install Fixture (Figure 3) on following page

CAUTION: BE SURE POWER IS OFF AT THE MAIN BREAKER BOX PRIOR TO INSTALLATION.

1. Thread jam nut (D) and crossbar (C) onto threaded nipple (E) with ground screw (F) facing towards swivel (I); leave both parts loose.
2. Using two machine screws (not provided), temporarily fasten crossbar (C) to the electric box.

NOTE: A NEW ELECTRIC BOX COMES WITH SCREWS. WHEN REPLACING A FIXTURE, RETAIN THE EXISTING SCREWS FOR USE WITH THE NEW FIXTURE.

3. Adjust the length of threaded nipple (E) in crossbar (C) so that canopy ring (G) will hold the canopy (H) against the ceiling with no threads showing for best appearance. When the correct adjustment is established, tighten jam nut (D) against crossbar (C) to secure the adjustment.
4. Remove crossbar (C) from the electrical box and proceed with the assembly instructions.
5. Provided are multiple fixture pipes (J,K,L) in three different lengths. Choose combination that will achieve the overall height desired. Refer to table below to determine pipes required to reach desired overall height. Once you have determined components necessary, feed wires that exit fixture (A) through the individual components and thread pipes and couplings together. If using no pipes for the shortest possible height, swivel (I) will thread directly onto threaded nipple (E). Wires will slip easier through loose components than through pipes and couplings that are pre-assembled. Once wires are run, apply thread locking compound to all connection points and assemble pipes and nipples.

		Overall Height of Fixture															
		32.3	35.3	38.3	41.3	44.3	47.3	50.3	53.3	56.3	59.3	62.3	65.3	68.3	71.3	74.3	77.3
# of Pipes Required	3" Pipe (J)		1		1		1		1		1		1		1		1
	6" Pipe (K)			1	1			1	1			1	1			1	1
	12" Pipe (L)					1	1	1	1	2	2	2	2	3	3	3	3

NOTE: APPLICATION OF THE THREAD LOCKING COMPOUND IS NECESSARY TO PREVENT THE PIPE FROM LOOSENING DURING REGULAR MAINTENANCE AND CLEANING OF THE FIXTURE. BE CERTAIN TO APPLY THE COMPOUND.

6. Carefully slide canopy ring (G) and canopy (H) over wires and fixture pipes (J,K,L) until they rest on fixture (A).
7. Slip wires from the fixture (A) through nipple (M) and assembled swivel (I).
8. Using two machine screws (not provided), fasten crossbar (C) to the electric box.
9. Using suitable wire connectors (not provided) re-attach fixture wires to supply (white/ribbed to white and black/smooth to black). Attach a pigtail lead to crossbar ground screw (F). Hold canopy (H) close, connect all ground wires (bare copper or green to bare copper or green).

CAUTION: MAKE SURE WIRE CONNECTORS ARE TWISTED ON SECURELY, AND NO BARE WIRE IS EXPOSED.


SPIRE PENDANT 181604

Install Bulb & Complete Installation *(Figure 3)*

10. Slide canopy (H) against ceiling, and secure with canopy ring (G).

CAUTION: BE SURE NO WIRES ARE PINCHED BETWEEN CANOPY (H) AND THE CEILING.

11. Install bulb (R) (not included).
12. Restore electricity at main breaker.



(Figure 3)

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!
 * *Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.*