
# VISUAL COMFORT & CO.


STUDIO COLLECTION

## LOWELL LARGE SCONCE

EW1201







### **INSTRUCTIONS**

#### I. Preparing the Fixture

1. Separate the mounting plate from the fixture base by removing the fixture screws.

#### II. Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
- In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
- 3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
  - a) Hot fixture wire (black) and hot power line wire from the junction box (hot to hot)
  - b) Neutral fixture wire (white) and neutral power line wire from the junction box (neutral to neutral)
- 4. Carefully tuck all the wires behind the mounting plate into the junction box.

#### III. Installing the Fixture

- 1. Mount the fixture onto the mounting plate and secure it in place by reinstalling the fixture screws.
- 2. Affix the shade onto the fixture using the shade ring to secure it.
- 3. Install the bulb into the socket, referring to the label on the socket for Max Wattage information.