


ASSEMBLY INSTRUCTIONS



Circon 5" Mini Pendant

Item # WF5100

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

9. Connect fixture neutral wire (black) to driver (F) output wire (black) using wire nut (A).
10. Connect fixture hot wire (red) to driver (F) output wire (red) using wire nut (A).
11. Connect supply ground wire (usually green or bare copper) and fliter (J) ground wire (yellow and green) around the green grounding screw (see diagram 2). Tighten.

NOTE: It is imperative that the fixture is grounded.

12. Connect fliter (J) input neutral wire (white) to the supply neutral wire (usually white) using wire nut (A).
13. Connect fliter (J) input hot wire (black) to the supply hot wire (usually black) using wire nut (A).

CAUTION: Do not reverse the hot and neutral connections.

14. Make sure all wire connections are tight, then carefully tuck into the junction box.
15. Install driver (F) and canopy (G) to mounting plate (B) and secure with collar ring (H).
16. Thread shade (E) and fixture (I).

NOTE: Do not overtighten otherwise shade could become damaged.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

WATERFORD

IRELAND 1783

