

SUMA MEDIUM PENDANT

DJP1251

General Product Information



ETL LISTED
Intertek



SAVE THESE INSTRUCTIONS!



STANDARD INSTALLATION



INDOOR



DAMP LOCATION SAFE



NEC COMPLIANT JUNCTION BOX



LED



PLEASE SEE visualcomfort.com FOR PRODUCT SPECS



CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!



BEST PRACTICE: HANDLE FIXTURE WITH GLOVES




Product Warranty




FCC Statement


Suggested/Required Tools




ELECTRIC DRILL



PHILLIPS-HEAD SCREWDRIVER



PENCIL/MARKER




WIRE CUTTER

Safety Information

CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.





FIXTURE PARTS

- A. Junction Box
- B. Wire Nut Connections
- C. Mounting Plate with Screw Collar & Mounting Screws (Not Illustrated)
- D. Half Ball Assembly
- E. Canopy
- F. Collar Nut
- G. Fixture Cord/Wires
- H. Stem Assembly
- I. Socket
- J. LED
- K. Fixture Shade
- L. Fixture Plate
- M. Globe Shade

INSTRUCTIONS

I. Preparing the Fixture

1. Carefully unbox and examine all the items included in the packaging of the fixture.
2. Locate the mounting plate with screw collar and secure it to the junction box using the mounting screws.
3. Determine the desired height of the fixture and complete the stem assembly, accordingly, by screwing the stems together.
4. Secure the stem assembly on top of the fixture.
5. Feed the fixture wires through the stem assembly, collar nut, canopy, and half ball assembly.
6. Secure the half ball assembly onto the stem assembly.
7. Slide the outer glass shade through the socket assembly carefully.
8. Insert the LED into the socket. Refer to the label on the socket for max wattage information. Screw the globe shade onto the socket assembly.
9. Lift the assembled fixture carefully and slide the half ball assembly onto the screw collar portion of the mounting plate.

II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire (black, smooth) to hot power line wire
 - b) Neutral fixture wire (white, textured) to neutral power line wire
4. Carefully tuck all the wires behind the mounting plate into the junction box.

III. Installing the Fixture

1. Place the canopy onto the mounting plate with screw collar and secure it in place by screwing the collar nut tightly onto it.
2. Adjust the outer glass shade as needed so it is positioned straight on the glass globe.