

VISUAL COMFORT & CO.

STUDIO COLLECTION


RUXTON SMALL OUTDOOR WALL TF01031











FIXTURE PARTS

- A. Junction Box
- B. Fixture Wires
- C. Mounting Plate & Mounting Screws (Not Illustrated)
- D. Fixture Screws
- E. Fixture
- F. Bulb (Not Included)

INSTRUCTIONS

I. Preparing the Fixture

- 1. Separate the mounting plate from the fixture backplate.
- 2. Install the mounting plate to the junction box and secure it using the mounting screws.

II. Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
- In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
- 3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire (black) to hot power line wire
 - b) Neutral fixture wire (white) to neutral power line wire
- 4. Carefully tuck all the wires into the junction box.

III. Installing the Fixture

- 1. Install the fixture onto the mounting plate and secure it in place by screwing in the fixture screws.
- 2. Screw the bulb into the socket. Refer to the label on the socket for max wattage information.
- 3. For wet locations, caulk around the base of the fixture with waterproof construction sealant.