




BUCKNER SMALL, MEDIUM, & TALL PENDANTS

TFP1051; TFP1041; TFP1031

General Product Information

Please visit www.visualcomfort.com for product specs.



Suggested/Required Tools



Safety Information

CAUTION-RISK OF FIRE



This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.





FIXTURE PARTS

- A. Junction Box
- B. Wire Nuts
- C. Mounting Bar
- D. Screw Collar
- E. Collar Loop
- F. Canopy
- G. Collar Nut
- H. Quick Links
- I. Chain
- J. Fixture Loop
- K. Fixture
- L. Bulb (Not Included)

INSTRUCTIONS

I. Preparing the Fixture

1. Secure the mounting plate to the junction box.

II. Installing the Fixture

1. Determine desired overall length, and amount of chain needed. Shorten chain using chain pliers. (Keep extra chain)
2. Screw the fixture loop onto the top of the fixture. Attach chain to the fixture loop using quick link. Secure quick link.
3. Thread fixture wire and ground wire through chain. NOTE: When you reach the collar loop, ensure there is no tension on the wires. Cut excess wires, being sure to leave about 12" to reach the junction box.
4. Loosen collar nut and let the collar nut and canopy slip down chain carefully. Then attach chain to the collar loop using quick link. Secure quick link.
5. Screw on bulb into the socket. Refer to the label on the socket for Max Wattage Information.

III. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire (black, smooth) and hot power line wire from the junction box (hot to hot)
 - b) Neutral fixture wire (white, textured) and neutral power line wire from the junction box (neutral to neutral)
4. Carefully tuck all wires into the junction box. Place the canopy onto the mounting plate and secure it in place by screwing the collar nut tightly onto the mounting plate.