

MODERN COLLECTION

TALA 15 & 25 PENDANTS

MDPD736; MDPD737

General Product Information





























Suggested/Required Tools









Safety Information

CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.





FIXTURE PARTS

- A. Junction box
- B. Wire Nut Connections
- C. Drive
- D. Mounting Plate with Screw Collar
- E. Mounting Screws
- F. Hall Ball
- G. Canopy
- H. Collar Nut
- I. Stem Assembly
- J. Glass Shade
- K. Fixture

INSTRUCTIONS

I. Preparing the Canopy

- 1. Unbox and inspect all items included in the fixture's packaging. Handle the glass shade with care to prevent damage.
- 2. If necessary, separate the mounting plate with screw collar from the canopy by removing the collar nut.
- 3. Determine the height for the fixture and complete the stem assembly by screwing the long and short stems together to the desired length.
- 4. Feed the fixture wires through the glass shade, stem assembly, collar nut, canopy, and half ball.
- 5. Screw the stem assembly onto the top of the fixture, then screw the half ball onto the top of the stem assembly.

II. Installing the Mounting Plate & Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
- 2. Connect the LED driver input wires to the local power line wires. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Neutral driver wire (white) to neutral power line wire
 - b) Hot driver wire (black) to hot power line wire
- 3. Ensuring the driver output wires are accessible, secure the mounting plate with screw collar to the junction box using the mounting screws.
- 4. Slide the half ball assembly onto the screw collar portion of the mounting plate.
- 5. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
- 6. Connect the following pairs of wires using wire nuts (skip this step if the wires come pre-connected out of the package):
 - a) Negative (-/blue) fixture wire to negative (-) output driver wire
 - b) Positive (+/red) fixture wire to positive (+) output driver wire
- 7. Carefully tuck all the wires behind the mounting plate into the junction box.
- 8. Place the canopy onto the mounting plate and secure it in place by screwing the collar nut tightly onto it to finish installation.
- 9. Turn the power back on at the breaker and test the fixture to ensure proper operation.