



# ASSEMBLY INSTRUCTIONS FOR YOUR HATTERAS SCONCE

## IMPORTANT SAFETY INSTRUCTIONS:

- \* These instructions are provided for your safety. It's important that all safety instructions are read before beginning installation of fixture.
- \* We **STRONGLY** recommend installation by a licensed electrician.
- \* Turn off power at switch before replacing bulbs, making sure fixture has sufficient time to cool down.
- \* Do not connect the electricity until lamp is fully assembled.
- \* This fixture is UL rated for dry locations.

## CORD COVER ASSEMBLY INSTRUCTIONS:

1. Remove mounting plate (B) from backplate (G) by removing screws (K).
2. Determine desired location for light fixture on wall. Hold mounting plate (B) in a level position against the wall. Using a pencil, mark the location of the mounting holes in mounting plate (B) onto the wall.
3. Drill small holes at marked locations on the wall. Holes should be sized so they accommodate wall anchors (A), provided. Insert wall anchors into drilled holes.
4. Affix mounting plate (B) to the wall by threading mounting screws (C) through holes in mounting plate (B) and into wall anchors (A).
5. Slide backplate (G) over mounting plate (B). Thread screws (K) back into holes at the top and sides of backplate (G) to secure fixture to the mounting plate (B).
6. Thread cord cover (I) into the bottom of the backplate (G).
7. Remove flange (M) from socket (J). Slide candle follower of shade (L) over socket (J) and let shade (L) rest on the lip of the socket cup. Thread flange (M) onto socket (J) to affix the shade to the sconce.
8. Insert one dimmable candelabra base 60W Max. incandescent equivalent LED bulb into socket (J).  
Bulb not included.
9. Plug 3-prong plug into outlet and test dimming by using turn knob 1 on backplate (G).

## DIRECT WIRE ASSEMBLY INSTRUCTIONS:

1. Remove mounting plate (B) from backplate (G) by removing screws (K).
2. From the back side of backplate (G), pull the electrical cord up through the hole in the bottom of backplate (G). At least six inches of wire will be needed to make proper electrical connections.
3. Remove the bottom plug from backplate (G) and insert plug (H) in the vacant threaded hole.
4. Pass the power cable (F) through the sleeve (I) and fix it with the eight-loop clip (E).
5. Lift fixture to mounting plate and make proper electrical connections described in steps 6 - 8.  
**A LICENSED ELECTRICIAN IS RECOMMENDED.**
6. Connect ground (green or silver in color) wire from fixture to ground wire in the backplate. Fasten wires together with wire nut (D) and tightly wrap the connection with electrical tape.
7. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from backplate. Fasten wires together with wire nut (D) and tightly wrap connection with electrical tape.
8. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from backplate. Fasten wires together with wire nut (D) and tightly wrap connection with electrical tape. Gently push wire connections back into J-Box.
9. Slide backplate (G) over mounting plate (B). Thread screws (K) back into holes at the top and sides of backplate (G) to secure fixture to the mounting plate (B).
10. Remove flange (M) from socket (J). Slide candle follower of shade (L) over socket (J) and let shade (L) rest on the lip of the socket cup. Thread flange (M) onto socket (J) to affix the shade to the sconce.
11. Insert one dimmable candelabra base 60W Max. incandescent equivalent LED bulb into socket (J).  
Bulb not included.
12. Reconnect main electrical supply at the fuse box/circuit breaker. Test dimming by using turn knob 1 on backplate (G).

