904-FJ-LPIP-01



1718 W. Fullerton Ave Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613 www.edgelighting.com info@edgelighting.com



1.5MM ALLEN

M3 SET

SCREW

WRENCH


Installation Instructions for Fast Jack LED Pipe Pendant

IMPORTANT INFORMATION

- This product is ETL listed for indoor dry locations.
- The product is intended to be used with Edge Lighting Monorail systems only.

SAVE THESE INSTRUCTIONS!

Adjust the Fixture Height



1: Cut the coaxial cable to the desired height (H) with a sharp cutter. The overall fixture height is measured from the bottom of the metal shade to the end of the coaxial cable.




B

2MM ALLEN


WRENCH


- **3:** Remove the M3 set screw on tip of the connector with the 1.5mm Allen wrench provided.
- **4:** Feed the coaxial cable through the conical nipple and flared side of the strain relief tube. Slide the conical nipple and strain relief tube down the coaxial cable.

COAXIAL FIXTURE CONNECTOR




5: Feed the coaxial cable into the coaxial fixture connector. The coaxial cable will come to a stop point.






- **6:** Keep feeding the coaxial cable in until the inner wire is visible in the screw hole of the fixture connector tip. The outer metal jacket will start to wrinkle.
- 7: Hold the fixture connector in place. Replace and tighten the M3 set screw on fixture connector tip with the 1.5mm Allen wrench.
- 8: Pull down the outer metal jacket to smooth the wrinkles.



- 9: Push the strain relief tube completely into the coaxial fixture connector. Make sure the slot on the strain relief tube is not inline with the M4 set screw.
- 10: Tighten the M4 set screw with the 2mm Allen wrench.



- **12:** Refer to the instructions provided with the Monorail 2 Circuit fixture connector to choose Circuit #1 or Circuit #2.
- **NOTE:** The LED Pipe head consumes **8** watts and contains integrated LED lamps which are rated for 50,000 hours.