



CONTENTS

Laddi Pendant 01 Lighting Assembly




(x2) 8-32 Screw




(x5) Wago Connector




(x1) Driver




Cover tube  
with threaded  
stem




Glass shade



Star shaped canopy




(x2) Toggle anchor  
On 240V fixtures only



(x2) Wood screw  
On 240V fixtures only



(x2) Long 8-32 screw  
On 240V fixtures only



(x2) Metal screw  
On 240V fixtures only



SAFETY INFORMATION

Suitable for dry or damp locations.  
The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

## Laddi Pendant 01 | INSTALLATION

### Cord length adjustment


*Note: Please contact a licensed electrician.*

### Example fixture only:

To measure length of cord, first determine overall length (OAL), subtract 2" for the canopy height and subtract the fixture height from the OAL.  
Fixture height is measured from bottom of the fixture to stem connection point.  
The resulting measurement is the final stem length.

Ex. The fixture below has an OAL of 40" and a fixture height of 7.8".  
40" OAL - 2" canopy - 7.8" fixture height = 31" cord

Note: leave extra 6" cord length to pass through the canopy and make the wire connection.




## Laddi Pendant 01 | INSTALLATION

### Stem and cover tube length adjustment


*Note: Please contact a licensed electrician.*

#### Example fixture only:


1. To customize the length of the provided stem, cut cover tube to desired length.  
Then cut the inner threaded tube so that it remains  $7/8"$  longer than the cover tube.




2. Mark the length of the tube required, using a marker or tape. Then hold down the tube with a hand or a clamp, use a hacksaw or electrical tool to cut the tube. Recommended to clean tube after cutting to remove any metal chippings.



3. Now that the cover tube is cut to  $32"$ , measure the all thread tube to be  $32$  and  $7/8"$  long. And place a mark, with a marker or tape.




4. Hold down the all thread with a hand or a clamp, use a hacksaw or electrical tool to cut the all thread tube. Recommended to clean all thread tube after cutting to remove any metal chippings.



## Laddi Pendant 01 | INSTALLATION

*Note: Please contact a licensed electrician for installation. Ensure power is off during installation.*


01. Unscrew the canopy nut (A) from the star canopy (B), to release the crossbar assembly (C).



## Laddi Pendant 01 | INSTALLATION

*Note: Please contact a licensed electrician for installation. Ensure power is off during installation.*


02. Take the main fixture assembly (D), and screw in the threaded rod (E) into the fixture, then slide on the cover tube (F).
03. Slide the canopy nut (A), and star canopy (B) onto the stem.
04. Then screw on the crossbar assembly (C) onto the threaded rod.
05. Be sure to pull the wires through each, and out on the side of the crossbar hickey.



## Laddi Pendant 01 | INSTALLATION

*Note: Please contact a licensed electrician for installation. Ensure power is off during installation.*

06. Bring the LED driver (G) to the J-box(H). then make the lead wire connection with the provided 2-port wagos (I).
07. Optional, make the dimming wire connection with the provided 2-port wagos (J).
08. Tuck the LED driver into the J-box, be sure to pull out the green ground wire.
09. Bring the fixture up to J-box, and make the ground wire connection with provided 2-port wagos (K).
10. Then make the low voltage wire connection with provided 2-port wagos (L).
11. Tuck in all wires back into J-box, and secure the crossbar (C) to J-box (H) with the provided two screws (M).
12. Raise the star canopy (B) over the J-box, and secure it with canopy nut (A).



## Laddi Pendant 01 | INSTALLATION

*Note: Please contact a licensed electrician for installation. Ensure power is off during installation.*

13. Unscrew the shade cover (N) from the main fixture (D).
14. Secure the Glass shade (O) on to the main fixture (D) with a shade cover (N).  
Be sure to align the glass with the rubber gasket for even glass fitment.

