
VISUAL COMFORT & CO.


MODERN COLLECTION

PONTE 7 TASK SCONCE

SLTS678







INSTRUCTIONS

I. Preparing for Installation

- 1. Carefully unbox and examine all items included in the fixture's packaging.
- 2. Separate the mounting plate from the fixture's backplate by removing the fixture screws.

II. Wiring the Fixture & Installing the Mounting Plate

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits, ensuring there's no electricity running through the wiring.
- 2. To install a junction box with an attached mounting plate, do the following:
 - a) Mark the anchor locations on the wall.
 - b) Drill holes at the marked locations and install the anchors.
 - c) Align the junction box and secure it with anchor screws, ensuring it is level and tightly fixed in place.
- 3. Connect the LED driver input wires to the local power line wires. Twist the bare ends of the following pairs of wires together using a wire nut to secure the connection:
 - a) Neutral driver wire (blue) to neutral power line wire.
 - b) Hot driver wire (brown) to hot power line wire.
- 4. Place the driver in the junction box, ensuring the output driver wires are accessible.
- 5. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to a suitable ground. This may be a green ground screw on the mounting plate, to which the ground wire should be tightly wrapped, or to a house wire (green or bare copper wire without insulation).
- 6. Twist the bare ends of the following pairs of wires together using a wire nut to secure the connection:
 - a) Black (negative) driver wire (output) to black fixture wire.
 - b) Red (positive) driver wire (output) to red fixture wire.
- 7. Carefully tuck all the wires into the junction box.

III. Installing the Fixture

- 1. Place the fixture backplate/base onto the mounting plate portion of the junction box and secure it in place with the fixture screws.
- 2. Pivot the fixture head (up and down: up to 90°/right and left: 60°) to direct the light as desired.

2