


1718 W. Fullerton Chicago, IL 60614 Ph: 773.770.1195 • Fax: 773.935.5613 www.PureEdgeLighting.com • info@PureEdgeLighting.com © 2016 PureEdge Lighting. All Rights Reserved.

Installation Instructions for 60 Watt 24 Volt DC Power Supply with 0-10 Volt Dimming Module




SAVE THESE INSTRUCTIONS!





GENERAL INFORMATION - <u>RISK OF FIRE:</u> This product must be installed by a qualified electrician. Turn the power to the electrical box off during installation. Read the "Important Safety Instructions" before installation.	 IMPORTANT SAFETY INSTRUCTIONS Do not install this power supply in a wet location. To reduce the risk of the system overheating and possibly causing a fire, make sure all the connections are tight. 		
- NOTE: To avoid overheating the power supply, install it in a ventilated remote location where air flows. Maintain proper spacing among power supplies when multiple power supplies are installed in the same remote location.	- Do not install *LED fixture closer than 3" or as specified in the *LED fixture installation instructions to curtains or similarly combustible materials. Keep insulation at least 3" away from the enclosure.		
 This product is not suitable for wet locations. It is approved for the use at any height above the finished floor. 	- Turn the electrical power off before modifying the lighting system in any way.		
 A typical installation is shown. Specific installation must be in accordance with the local electrical codes. <u>TO REDUCE RISK OF FIRE</u>, it is important to wire the power supply for the system as described in this installation instruction. 	 The system is "ETL" listed for USA and Canada only when all the products used are supplied by Edge Lighting. *See LED fixture installation instructions for proper placement. 		
- Load the power supply to MAXIMUM 60 Watts.			
- Use Philips: Sunrise "SR1200TUNV" 0-10 volt controller to dim the LED soft strip (fixture).			
- For multiple parallel runs, do not exceed 32' total length.			

Wiring Diagram





Install the Power Supply






- **5:** Secure the controller to the electrical box.
- **6:** Run the power line wires from the panel to the input enclosure on the power supply.
- 7: **<u>DO NOT</u>** connect the power wires to the panel at this time.







60W, 24VDC LOW VOLTAGE WIRE SIZE CHART						
3% VOLTAGE DROP	WIRE LENGTH IN FT	UP TO 53FT	54FT - 82FT	83FT - 137FT	138FT - 208FT	
	WIRE SIZE	14 AWG	12 AWG	10 AWG	8 AWG	
	VOLTAGE AT END OF THE WIRE	23.29 VDC	23.28 VDC	23.28 VDC	23.28 VDC	