STUDIO COLLECTION

GRAYSON MEDIUM FLOOR LAMP

LT1241

General Product Information: SAVE THESE INDOOR Intertek PLEASE SEE VISUALCOMFORT.COM FOR PRODUCT SPECS BULBISS (NOT INCLUDED) CONVERTS TO LED POLARIZED PLUG BEST PRACTICE: HANDLE FIXTURE WITH GLOVES CLEAN WITH SOFT, DRY CLOTH ONLY, NO HARSH CHEMICAL ST

Safety Information

Product Warranty

IMPORTANT SAFETY INSTRUCTIONS


This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

FCC Statement

Install and use this product in adherence with local electrical codes and regulations.



FIXTURE PARTS

- A. Finial
- B. Lamp Shade
- C. Harp Nipple
- D. Harp
- E. Bulb (Not Included)
- F. Socket
- G. On/Off Switch
- H. Saddle
- I. Stem
- J. Lamp Base
- K. Power Cord with Polarized Plug
- L. Included Tool



INSTRUCTIONS

- 1. Carefully unbox and examine all the items included in the packaging of the lamp.
- 2. Use the included tool to secure the fixture stem to the lamp base.
- 3. Install the harp by squeezing it together and inserting it into the top of the saddle.
- 4. Remove the finial from the harp.
- 5. Next, remove the shade from its packaging and affix it to the harp.
- 6. Secure the finial to the lamp.
- 7. Screw the light bulb into the socket. Refer to the label on the socket for max wattage information.
- 8. Plug the lamp into a working electrical socket.
- 9. Use the switch to turn the lamp on/off to test for proper functioning.