


Installation Instructions for Monorail 4" Round Single Power Feed Canopy with 60 Watt 12 Volt Electronic LED Transformer


IMPORTANT INFORMATION

- This product is ETL listed for indoor dry locations.
- This product can be installed to a 4" electrical box with round plaster ring, or to an octagon electrical box.
- Minimum electrical box volume must be 6 cubic inches (98 cubic centimeters).
- This product should be installed by a qualified electrician.

SAVE THESE INSTRUCTIONS!





Install the Electronic Transformer & Canopy



- 1: Turn the power to electrical box off.
- 2: Connect the white transformer wire to the neutral power wire with a wire nut.
- 3: Connect the black transformer wire to the hot power wire with a wire nut.
- 4: Place the transformer and transformer wires inside the electrical box.

NOTE: Use the universal round crossbar (provided) if the electrical box holes are not spaced 2-3/4" apart.


- 5: Connect each low voltage wire transformer to one power feed canopy wire with a wire nut.



- 6: Place all wires inside the electrical box.
- 7: Secure the power feed canopy to the electrical box by tightening the two provided #8-32 screws with the 3/32 Allen wrench.

Install the Monorail to Power Feed Canopy

D




1: Unscrew the cap from power housing.

2: Slightly loosen the 3/8-24 set screw on the cap with the 3/16 Allen wrench provided, **DO NOT REMOVE IT.**

3: Place the Monorail into the power housing. Make sure that the Monorail is supported by the standoffs. Refer to the instructions provided with the standoffs.

4: Tighten the cap to the power housing. **Make sure the cap is not cross threaded.**

E



5: Tighten the 3/8-24 set screw on the cap firmly with the 3/16 Allen wrench provided for proper power connection.

CAUTION: Risk of Fire: MAX load of Fast Jack LED canopy is 60 watt.

F

